

Experiment 1: Calibration of Venturimeter and Orifice Meter

Name: Manav Doshi

Roll Number - 200100094

Aim - To calibrate Venturimeter and Orifice Plate for a given fluid and study variation of coefficient of discharge C_d with Reynold's Number

Working and Calculations:

For venturimeter:

Given: $\beta = d/D = 0.697$

Supply pipe diameter = 21 mm

$D(\text{inlet}) = 21.5 \text{ mm}$

$d(\text{throat}) = 15 \text{ mm}$

$\rho_w = 1000 \text{ kg/m}^3$

$\mu = 0.0007975 \text{ Pa.s}$

$\rho_{Hg} = 13600 \text{ kg/m}^3$

$C_d(150) = 0.984$

Taking head loss

$$Q_{act} = \frac{10 \times 10^{-3}}{17.3} = 5.78 \times 10^{-4} \text{ m}^3/\text{s}$$

Reynold's number

$$Re_d = \frac{4 \rho_w Q_{act}}{\pi (D(\text{Supply Diameter})) \times \mu} = \frac{4 \times 1000 \times 5.78 \times 10^{-4}}{\pi \times 21 \times 10^{-3} \times 0.0007975} = \frac{42989.2}{43745.5}$$

$$h_w = \left(\frac{S_{Hg}}{S_w} - 1 \right) h_{Hg}$$

$$= 12.6 \times 86 = 1083.6 \text{ mm}$$

$$Q_{th} = \frac{\pi D^4}{4} \sqrt{\frac{2 \Delta p}{S_w (1 - \beta^4)}} = \frac{\pi \times (15 \times 10^{-3})^4}{4} \sqrt{\frac{2 \times 9.81 \times 1000 \times 1083.6 \times 10^{-3}}{1000 (1 - 0.697^4)}}$$

$$= 6.04 \text{ m}^3/\text{s}$$

$$C_d = \frac{Q_{th} Q_{act}}{Q_{th}} = 0.958$$

We can see that the results match with the excel sheet

For orifice :

$$\text{Given } \beta = 0.7$$

$$\text{Supply pipe diameter} = 21 \text{ mm}$$

$$D(\text{inlet}) = 20 \text{ mm}$$

$$d(\text{throat}) = 14 \text{ mm}$$

$$S_w = 1000 \text{ kg/m}^3$$

$$\mu = 0.0007975 \text{ Pa.s}$$

$$S_{Hg} = 13600 \text{ kg/m}^3$$

Considering first row

$$Q_{act} = \frac{10 \times 10^{-6}}{18} = 5.55 \times 10^{-7} \text{ m}^3/\text{s}$$

$$R_{Re} = \frac{4 S_w Q_{act}}{\pi \times (\text{Supply Diameter}) \times \mu} = \frac{4 \times 1000 \times 5.55 \times 10^{-7}}{\pi \times 21 \times 10^{-3} \times 0.0007975} = 48986.47$$

$$h_w = \left(\frac{S_{Hg}}{S_w} - 1 \right) h_{Hg}$$

$$\therefore 12.6 \times 10^5 = 1383 \text{ mm}$$

$$Q_{th} = \frac{\pi d^3}{4} \sqrt{\frac{2 \Delta p}{S_w (1 - \beta^4)}}$$

$$= \frac{\pi \times (14 \times 10^{-3})^3}{4} \sqrt{\frac{2 \times 1000 \times 9.81 \times 1383 \times 10^{-3}}{1000 (1 - 0.7^4)}}$$

$$= 8.9969 \times 10^{-4}$$

$$C_d(\text{act}) = \frac{Q_{\text{act}}}{Q_{th}} = 0.617$$

$$C_d(180) = 0.5981 + 0.09261 \beta^2 - 0.216 \beta^6 + 0.000521 \left(\frac{10^6 \beta}{Re_d} \right)^{0.7} = 0.600156$$

These match with values in the excel sheet

Sources of error:

- we calculate the volume flow as Axv , but this might be inaccurate as we consider velocity to be uniform over the cross section, which it isn't.
- Eddies ^{forming} in the orifice meter cause flow separation causing energy dissipation.
- The throat diameter ^d which we use to calculate β is larger than the actual diameter of the vena contracta where pressure is measured.

Questions

- Venturimeter has a lower amount of flow separation and turbulence and hence the amount of energy dissipation is low. On the contrary, eddies ^{form} in orifice meter due to ~~causes~~ flow separation. Also since we used throat diameter instead of vena contracta, C_d gets affected.
- When fluid flows through the converging section of the venturimeter, it gains kinetic energy. This is converted back to pressure head in the diverging section. If the diverging angle is large, the pressure would increase rapidly ~~causing~~ causing flow separation from the wall of the venturimeter. This generates eddies and pressure losses due to friction of the fluid. Hence, the diverging angle is kept small to reduce the chances of flow separation and keeping pressure efficiency as high as possible.

Question 11


- Vena-contracta is the point in the stream where diameter of the stream is the least and fluid velocity is maximum. Curvature in streamline causes velocity to vary a lot in a cross section. This happens due to centrifugal force. In the throat of orifice meter, there is a large curvature as the flow changes from here. At the vena-contracta, the velocity is almost uniform and the streamlines are almost parallel.

we can measure pressure accurately at the vena-contracta.

Q3) A low P static means that the plate has a smaller hole and a higher pressure drop. This would require a larger pump to operate and also more money. Higher P static means low differential pressure across the orifice which may be difficult to measure.

Venturi meter ($\beta=d/D$) = 0.697

| Sr. No. | Volume V(Litres) | Time t (sec) | Qact (m ³ /s) *10 ⁻⁴ | ReD | Manometer Reading hm (mm Hg) | Manometer Reading hw (mm water) | Qth (m ³ /s) *10 ⁻⁴ | Cd (Expt) | Cd (ISO) |
|---------|---------------------|-----------------|---|-------------|---------------------------------|------------------------------------|--|--------------|-------------|
| 1 | 10 | 17.3 | 5.780346821 | 43945.46144 | 36 | 453.6 | 6.035748943 | 0.958 | 0.984 |
| 2 | 10 | 21.65 | 4.618937644 | 35115.77288 | 25 | 315 | 5.029790786 | 0.918 | 0.984 |
| 3 | 10 | 24.5 | 4.081632653 | 31030.87685 | 17 | 214.2 | 4.147671737 | 0.984 | 0.984 |
| 4 | 10 | 27.5 | 3.636363636 | 27645.69029 | 14 | 176.4 | 3.763950769 | 0.966 | 0.984 |
| 5 | 10 | 41.8 | 2.392344498 | 18187.95414 | 7 | 88.2 | 2.661515113 | 0.899 | 0.984 |



Orifice Plate ($\beta=d/D$) = 0.7

| Sr. No. | Volume V(Litres) | Time t (sec) | Qact (m ³ /s)* 10-4 | ReD | Manomet (mm Hg) | Manometer Reading (mm water) | Qth (m ³ /s) * 10-4 | Cd (Expt) | Cd (ISO) |
|---------|---------------------|-----------------|-----------------------------------|-------------|--------------------|---------------------------------|-----------------------------------|--------------|-------------|
| 1 | 10 | 18 | 5.555555556 | 42236.47127 | 105 | 1323 | 8.996988266 | 0.617 | 0.6002 |
| 2 | 10 | 21.5 | 4.651162791 | 35360.76665 | 83 | 1045.8 | 7.999107821 | 0.581 | 0.6006 |
| 3 | 10 | 29.6 | 3.378378378 | 25684.34064 | 43 | 541.8 | 5.757536931 | 0.587 | 0.6017 |
| 4 | 10 | 37.41 | 2.673082064 | 20322.27968 | 21 | 264.6 | 4.023575471 | 0.664 | 0.6026 |
| 5 | 10 | 54.12 | 1.84774575 | 14047.60685 | 12 | 151.2 | 3.041537165 | 0.608 | 0.6045 |

